



Systems Specifications Metal Storage tanks

Surface Preparation: Ensure surfaces are degreased and free of contamination using [Protective Paints A925 - Metal degreaser](#) (follow instructions as per data sheet). Ensure all **Corroless data sheet** are strictly followed. Ensure surfaces are free from preparation debris and are clean and dry. Apply 1st coat within 4 hours of abrasive blasting. Practical coverage is project dependent. All data sheets can be found at the back of this manual.

DFT = Dry Film Thickness **WFT** = Wet Film thickness **TDF** = Total Dry Film thickness

Spec 010

<u>Exterior Moderate exposure</u>	Abrasive Blasting Sa 3 of AS 1627.9 (Two pack system)
<u>1st Coat</u>	Apply Corroless E at 80 µ WFT (50 µ DFT)
<u>2nd and 3rd coat</u>	Apply Corroless RF 60 at 50 µ WFT (30µ DFT) tinted to approved colour

TDF = 110 microns minimum

Spec 011

<u>External Exposure and chemicals</u>	Less Than 10 km from coastal areas of industrial activity Abrasive Blasting Sa 3 of AS 1627.9 (Two pack system)
<u>1st coat:</u>	Apply Corroless EP at 210 µ WFT(200 µ DFT)
<u>2nd and 3rd</u>	Apply Corroless RF 60 at 50 µ WFT (30 DFT) tinted to approved colour

TDF = 260 microns minimum

Spec 012

<u>Internal Metal Tanks Heavy Duty</u>	Tank Lining of Abrasive Blasting Sa 3 of AS 1627.9 (Two pack system)
<u>1st coat:</u>	Apply Corroless EP at 210 µ WFT(200 µ DFT)
<u>2nd and 3rd</u>	Apply Corroless RF 35 at 210 µ WFT (200 DFT)

TDF = 600 microns minimum

Protective Paints Ltd 0800 PAINT IT www.propaints.co.nz

Specification subject to NZS/AS 1627; Preparation of surfaces NZS/AS 2312 Protection of mild steel; AS 3894
Determination of Dry Film thickness